

ARTISAN #3


CONFIGURE THE AXES

By: Susan at <http://www.hukyforum.com/>
You may use this under the CC BY-NC-ND license.
(See <http://creativecommons.org/licenses/by-nc-nd/4.0/> for details.)

Setting up the Grid (Configure > Axes)

This section assumes you are setting up using Fahrenheit. If you are using Celsius, you will make some other choices, but the process will be the same.

Here is a sample grid and the page on which you set it up.



Axes ? X

Time Axis

☐ Lock

Min 00:00 Max 16:15

Step 1 minute Initial Max 14:00

Rotation 0 ☐ Lock Max

Temperature Axis

Min 100 Max 600

Step 50

DeltaBT/DeltaET Axis

Min 0 Max 50

Step 10

Legend Location

upper left

Grid

Style solid Width 1

Opacity 4

Defaults Cancel OK

Note that “Lock Max” is not checked”. If you leave it unlocked and for some reason your roast goes beyond the parameters you have specified, the grid will just keep expanding with your roast. If you lock it, you will stop recording as soon as you hit that max.

Initial Max 14:00

☐ Lock Max